

## TABLE OF ASCII CHARACTERS

The table below shows the numeric values for ASCII characters. These values are used for entering characters in the ticket editor as used in Rev. 1.38 and above for static weighing. Example: Capital letter "A" would be entered as numeric value 65 and lower case "a" would be 97.

ASCII	NUMERIC VALUE	ASCII	NUMERIC VALUE	ASCII	NUMERIC VALUE
SPACE	32	@	64	`	96
!	33	A	65	a	97
"	34	B	66	b	98
#	35	C	67	c	99
\$	36	D	68	d	100
%	37	E	69	e	101
&	38	F	70	f	102
'	39	G	71	g	103
(	40	H	72	h	104
)	41	I	73	i	105
*	42	J	74	j	106
+	43	K	75	k	107
,	44	L	76	l	108
-	45	M	77	m	109
.	46	N	78	n	110
/	47	O	79	o	111
0	48	P	80	p	112
1	49	Q	81	q	113
2	50	R	82	r	114
3	51	S	83	s	115
4	52	T	84	t	116
5	53	U	85	u	117
6	54	V	86	v	118
7	55	W	87	w	119
8	56	X	88	x	120
9	57	Y	89	y	121
:	58	Z	90	z	122
;	59	[	91	{	123
<	60	\	92		124
=	61	]	93	}	125
>	62	^	94	~	126
?	63	_	95		

### Special ASCII Characters

Carriage Return = 13

Line Feed = 10